Cryogenic cathodoluminescence of Cu_xAg_{1-x}InSe₂ thin films

Angel R. Aquino¹, Angus A. Rockett¹, Scott A. Little², Sylvain Marsillac²

¹Department of Materials Science & Engineering, University of Illinois, Urbana Illinois USA

²Wright Center for Photovoltaics Innovation and Commercialization, University of Toledo, Toledo Ohio USA


Motivation

- Cu(In,Ga)Se₂ is leading choice for high performance thin film solar cells (20.1% efficiency)
- Bandgaps of the I-III-VI, system (I-Cu,Ag; III-Ga,In; VI-S,Se) cover almost the entire solar spectrum, which make it an ideal system for multijunction solar cells
- · However, these make poor solar cells because most of their properties, including recombination mechanisms, are poorly understood
- · Cathodoluminescence (CL) offers simultaneous scanning of electron and spectroscopic images
- Our goals are to:
 - Study luminescence behavior close to grain boundaries
 - Identify emission differences between samples (Cu vs Ag)
 - · Characterize emissions and possible defects responsible
- First report of cryogenic CL with spectral imaging on AgInSe2 and CuxAg1-xInSe2


Experimental Setup

Thin film deposition system

- Hybrid sputtering/evaporation
- Sputtering of metals (Cu, Ag, In)
- •Substrate held at 550°C
- Three films analyzed
 - \bullet AgInSe $_2$ 300 nm
 - $\bullet Cu_{0.6}Ag_{0.4}InSe_2 700 \ nm$
 - •CuInSe₂ 700 nm



JEOL 7000F analytical SEM



- •Gatan MonoCL3 Spectrometer
- Liquid N₂-cooled Ge detector
- Liquid He-cooled stage module
- •Sample temperature ~ 5K
- Accelerating Voltage = 15 kV
- Current varied from 22 pA-160,000 pA
- · Some samples were carbon coated to avoid charging during imaging


Panchromatic CL Imaging


SEM Images

PanCL Images

Observations

- Very spatially uniform emissions
- Most dark areas in PanCL image correspond to dark areas in the SEM image
- Very few grains show reduced emission intensity from facets
- No reduction in emission intensity from protuberant surface features







- Much more spatial variation of emissions
- Dark areas in PanCL image correspond to bright areas in SEM image
- Severe reduction in emission intensity seen from protuberant surface features
- Very intense emissions coming from areas in between grains (dark areas in SEM
- Local variations in luminescence are indicative of local variation in defect states



- More spatial variation of emissions than in pure AgInSe2, but less than in $Cu_{0.6}Ag_{0.4}InSe_2$
- we approach surface facets or grain
- · Center of grains luminesce very well
- Intense emissions seen around grains

Power-series and Spectral Imaging







- At excitation powers above 2560 pA we see new exponential tails at both the high and low energy ends


· Blue shift of main Gaussian peak


- · No enhanced emission from grain boundaries or inter-grain areas
- Uniformity in emission indicates compositional uniformity





- Two Gaussians at low excitation power
- · Low and high energy end exponential tails appear at higher excitation powers together with additional Gaussian
- Blue shift of Gaussian peak
- Aligned and overlaid spectral images show spatial and spectral variation
- · Enhanced emission from grain boundaries and inter-grain areas
- CAIS has the most variation of emissions from grain to grain. indicating compositional fluctuations between grains





- · Very broad emission requires 4+ peaks to fit
- High energy (1200 nm) Gaussian starts emitting above 640 pA
- ·Blue shift of main Gaussian peaks
- Aligned and overlaid spectral images show spatial and spectral variation
- · Red emission, although very uniform, is most intense inside grains even close to facets and surface features
- · Green and blue emissions strongest from grain boundaries and inter-grain
- CIS has most emission variation from grain to boundary indicating compositional fluctuation between grain and grain boundaries

Conclusions

- Emissions from AgInSe2 are more uniform both spatially and spectrally than Cu-containing samples
- · AgInSe2 less affected by reduced emission from surface features partly due to less surface faceting
- · Cu-containing samples exhibit enhanced luminescence from grain boundary or inter-grain areas
- •Both Cu-containing samples exhibit localized luminescent variations indicative of compositional fluctuations or electrically active defect fluctuations
- ·As Cu increases, emission gets broader indicating larger number of specific defect states (more local
- •Device implications: AIS may produce more uniform cell performance and may exhibit less airsensitivity during manufacture

Acknowledgments

- Toledo acknowledgements: Ohio Department of Development (ODOD), Wright Center for Photovoltaics Innovation and Commercialization (PVIC)
- This work was supported by Air Force Research Laboratory, Space Vehicles Directorate, Kirtland AFB (Contract No. FA9453-08-C-0172)













